





DYNAMIS STOP SAFE



5 Low/Mid Treble Unit

OR **5** Tall Treble Unit



Low Treble Unit
6 RUNNER
H725 x W1060 x D420 with castors
H655 x W1060 x D420 with feet

○ **DYTL344**
(silver)
OR
○ **DYTL332**
(powder blue)

Mid Treble Unit
8 RUNNER
H935 x W1060 x D420 with castors
H865 x W1060 x D420 with feet

○ **DYTM344**
(silver)
OR
○ **DYTM332**
(powder blue)

Tall Treble Unit
H1705 x W1060 D420

2 x DYTM344
(silver)
OR
2 x DYTM332
(powder blue)
+
DYSTCK

**Low treble unit | 6 runner
DYTL344 OR DYTL332**

Parts list:

- X2: Main frame
- X4: Vertical support rail
- X1: Top horizontal rail
- X3: Middle horizontal rail
- X18: Bottom horizontal rail
- X1: Shelf
- X1: L-shaped bracket
- X1: Wrench
- X4: Casters
- X4: Casters
- X4: Casters
- X4: Casters
- X8: Screws (A)
- X8: Screws (C)

Assembly instructions:

- Attach the vertical support rail (X4) to the main frame (X2).
- Attach the top horizontal rail (X1) and middle horizontal rail (X3) to the main frame.
- Attach the bottom horizontal rail (X18) to the main frame.
- Attach the shelf (X1) to the bottom horizontal rail.
- Attach the L-shaped bracket (X1) to the main frame.
- Attach the casters (X4) to the bottom horizontal rail.

**Mid treble unit | 8 runner
DYTM344 OR DYTM332**

Parts list:

- X2: Main frame
- X4: Vertical support rail
- X1: Top horizontal rail
- X3: Middle horizontal rail
- X24: Bottom horizontal rail
- X1: Shelf
- X1: L-shaped bracket
- X1: Wrench
- X4: Casters
- X4: Casters
- X4: Casters
- X4: Casters
- X8: Screws (A)
- X8: Screws (C)

Assembly instructions:

- Attach the vertical support rail (X4) to the main frame (X2).
- Attach the top horizontal rail (X1) and middle horizontal rail (X3) to the main frame.
- Attach the bottom horizontal rail (X24) to the main frame.
- Attach the shelf (X1) to the bottom horizontal rail.
- Attach the L-shaped bracket (X1) to the main frame.
- Attach the casters (X4) to the bottom horizontal rail.

1

Parts list:

- X2: Main frame
- X1: Top horizontal rail
- X1: Middle horizontal rail
- RH X6 or x8: Right-hand horizontal rail
- LH X6 or x8: Left-hand horizontal rail

Assembly instructions:

- Attach the top horizontal rail (X1) and middle horizontal rail (X1) to the main frame (X2).
- Attach the right-hand horizontal rail (RH X6 or x8) and left-hand horizontal rail (LH X6 or x8) to the main frame.

2

Parts list:

- X1: Shelf
- RH X6 or x8: Right-hand horizontal rail
- LH X6 or x8: Left-hand horizontal rail

Assembly instructions:

- Attach the shelf (X1) to the right-hand horizontal rail (RH X6 or x8) and left-hand horizontal rail (LH X6 or x8).

3

Parts list:

- X2: Main frame
- X4: Vertical support rail
- X4: Screws (A)
- X4: Screws (C)

Assembly instructions:

- Attach the vertical support rail (X4) to the main frame (X2) using screws (A) and screws (C).